

## Remote Ballast Recommended Gang Mounting Distances

**Caution:** When gang-mounting remote ballasts it is recommended that the spacing between ballasts be kept at a minimum of 12 inches side to side and 12 inches top to bottom. Also it is recommended that installers mount ballasts directly above each other for a chimney effect. In equipment rooms there should be adequate ventilation to maintain rated ambient temperatures.

